

ATARI/OKIMATE 10

COMMAND REFERENCE CHART

This chart provides you with a quick reference to the programming commands described in this handbook. For most programming uses you'll need only the decimal code commands listed below. Ignore the hexadecimal codes unless you have special programming needs. Check the programming section of this handbook for further explanations of each of the commands.

<u>Function</u>	<u>Decimal</u>	<u>Hexadecimal</u>
Character sizes:		
Normal	27 15	1B 0F
Wide	27 15 27 14	1B 0F 1B 0E
Fine	27 20	1B 14
Bold	27 15 27 14	1B 14 1B 0E
Color printing:		
Align ribbon	153	99
End of line	155	9B
European characters:		
Start	27 23	1B 17
Stop	27 24	1B 18
Fine line advances:		
n/144" line advance	138 n	8A n
Formatting:		
CR and LF	155	9B
Advance to next page	140	8C
Perforation skip (OFF)	27 65	1B 41
Perforation skip (ON)	27 66	1B 42
Graphics:		
Start	27 37	1B 25
Stop	145	91
Repeat graphics	154 n data	9A n data
Lines per inch:		
6	27 54	1B 36
8	27 56	1B 38
Margin width:		
Standard	27 76	1B 4C
Narrow	27 83	1B 53
Starting position:		
Dot column	144 n	90 n